


TASER

P r o t e c t L i f e

User Transition Course * TASER® X26P™ Conducted Electrical Weapon (CEW)

Released April, 2013



TASER X26P

Conducted Electrical Weapon (CEW)



Prerequisite

- You must be a currently certified TASER Instructor or User
- This course is a supplement to the TASER Instructor and User Courses



TASER
TRAINING ACADEMY

Harsh Environment Resistant



X26P



TASER
TRAINING ACADEMY

X26P

- Designed for simple operation
- X26P safety, trigger and cartridge operate the same as the X26
- Download device data and firmware updates similar to the X2
- Same power source as the X2



TASER
TRAINING ACADEMY

Compact Size



X26



X26P



TASER
TRAINING ACADEMY

TASER X26P




TASER
TRAINING ACADEMY

TASER X26P



TASER
TRAINING ACADEMY

TASER X26P



TASER
TRAINING ACADEMY

X26P Safety Switch

- The ambidextrous safety switches do not operate independently of each other
- Do not block the Safety Switch on the side of the X26P while attempting to move it on the other side.
 - Blocking the safety switch can cause it to break and disable the X26P



TASER
TRAINING ACADEMY

Trigger Operation

- Single trigger pull and release discharges an electrical charge for a 5-second cycle
- Shift the Safety Switch down (SAFE) to stop a discharge at any time (e.g., if accidentally discharged)
- Holding the trigger continuously beyond the 5-second cycle will continue the electrical discharge until the trigger is released. The discharge will stop once the trigger is released after the initial 5-second cycle



TASER
TRAINING ACADEMY

Re-Energizing Cartridge

- Once a cartridge is fired, the operator can re-energize the cartridge by pulling the trigger
- Each trigger pull, when the X26P is not cycling, will initiate another 5-second cycle
 - Additional trigger pulls during the 5-second cycle will not extend the cycle unless the trigger is held back.



TASER
TRAINING ACADEMY


Central Information Display (CID)



TASER
TRAINING ACADEMY

Display Count Up

- Display will count up for single trigger pull (e.g., 1,2,3,4,5)
- Will continue to count up (e.g., 6,7,8...) if the trigger is held past the 5-second cycle



Power Source Status Icons

- Reads the battery consumption and displays the remaining battery life on the CID
- Battery pack should be changed or TASER Cam HD should be charged at $\leq 20\%$
- Battery bars in CID shows 20% increments



Battery
99%



Battery
80%



Battery
60%



Battery
40%



Battery
20%




Battery
0%
(Blinking)



Invalid PPM
(Blinking)

System Status Monitoring and Reporting

- The X26P monitors its system and functional status



NO ICONS
No problems
detected during
diagnostics



MAJOR FAULT
Likely accompanied
by a noticeable non-
essential subsystem
failure within the
X26P, like the
flashlight or LASER
not working, but
X26P can still be
used.



**CRITICAL
FAULT**
Indicates a
system failure.
This X26P is NOT
to be used for
duty.



TASER
TRAINING ACADEMY

Selector Switch

- Used to select the sighting options of the X26P and place the unit into stealth mode
- Use only your finger to depress the Selector Switch
 - Do not use objects like pens, paper clips or knives as this can result in switch breakage or the switch could become stuck



TASER
TRAINING ACADEMY

LASER and Light Settings

- OO - Stealth, no LASER, no flashlight
- LO - LASER only
- OF - Only flashlight
- LF - LASER and flashlight



OO
LO
OF
LF




TASER
TRAINING ACADEMY

Stealth Mode


- Pressing the Selector Switch when the Safety is in the up (ARMED) position will initiate Stealth Mode

- LASER and flashlight will turn off
- CID dims
- Press again or put the safety switch in the down (SAFE) position to cancel Stealth Mode



Performance Power Magazine (PPM)

- Contains three 3-volt lithium power cells
- Stores enough power for approximately 500+ five-second cycles



TASER
TRAINING ACADEMY

PPM Versions



APPM



TPPM



TASER Cam HD


Automatic-shutdown Performance Power Magazine (APPM) - designed to automatically stop the cycle after 5 seconds, even if the trigger is held down)

Tactical Performance Power Magazine (TPPM) - Extended finger grip

TASER Cam HD - Utilizes HD color video and functions similar to the original TASER Cam)



PPM Versions



Extended Performance Power Magazine (XPPM)

Provides 2nd cartridge storage while providing better protection for blast doors and orienting cartridge for reload if necessary



TASER
TRAINING ACADEMY

Extended Performance Power Magazine (XPPM)



TASER CAM HD



- 100 5-second cycles at optimum conditions
- 1 hour of audio/video at maximum resolution and 30 frames per second
- System recording is “looped”



TASER
TRAINING ACADEMY

TASER CAM HD



- System records both audio and video when the safety switch is in the up (ARMED) position
- Audio and video are configurable



TASER
TRAINING ACADEMY

TASER CAM HD



57

PPM Replacement



1. Press the PPM release button
2. Pull Down on the PPM



TASER
TRAINING ACADEMY

Current Metering

The X26P constantly measures its output, pulse-by-pulse, to optimize the output charge and increase the likelihood of Neuro-Muscular Incapacitation (NMI)



TASER
TRAINING ACADEMY

Spark Test

- A daily spark test should be conducted once every 24 hours or prior to the start of your shift for individually issued X26Ps
- The reason for the spark test is:
 - To check that the X26P is sparking
 - To check the battery performance



TASER
TRAINING ACADEMY

Spark Test

- One spark ($1/19^{\text{th}}$ of a second) is adequate. However this is not a practical duration. As long as the officer sees a visible spark between the electrodes, it is not necessary to extend the duration. In most cases, this takes less than 1 second



TASER
TRAINING ACADEMY

Spark Test

When conducting a spark test:

1. Follow agency protocol
2. Point in a safe direction
3. Remove the cartridge
4. Put safety switch in the up (ARMED) position
5. Pull the trigger



TASER
TRAINING ACADEMY

Spark Test

When conducting a spark test:

6. Visually and audibly inspect the arc
7. Put safety switch in the down (SAFE) position
8. Safely load the X26P before taking it into the field
9. Avoid developing poor muscle memory*



TASER
TRAINING ACADEMY

Pulse Calibration

- X26P is equipped with a pulse calibration system that measures the output of every single pulse
- Operator may detect a slight change in the pulse rate during 5 second spark test. This does not affect the X26P's effectiveness



TASER
TRAINING ACADEMY

Enhanced Data Logs

- Trilogy Logs
 - Event Log: tracks events and is similar to the X26 download
 - Pulse Log: records pulse activity
 - Engineering Log: monitors the performance of key sub-systems



TASER
TRAINING ACADEMY

Download

- X26P firing data can be uploaded to EVIDENCE.com via EVIDENCE Sync software
- EVIDENCE Sync software may also be used to download firing data to local computers



TASER
TRAINING ACADEMY

EVIDENCE.com

- Agency must establish an account on EVIDENCE.com
- There is no charge for EVIDENCE.com-Lite services
- Trilogy Logs can only be recovered and displayed through EVIDENCE.com



TASER
TRAINING ACADEMY

EVIDENCE Sync Upload

The screenshot displays the TASER Evidence SYNC web application. The interface is dark-themed with blue and white text. At the top, the title "EVIDENCE SYNC" is prominently displayed, followed by the version number "Ver. 1.31.2836.20-2837". On the right side of the header, there are links for "My Profile", "Help", and "Log out".

The main content area is divided into several sections:

- DEVICE SUMMARY:** Located on the left, it includes links for "Event Log", "Device Status", and "Firmware History".
- DEVICE INFORMATION:** This section features a yellow TASER device icon and the following details:
 - ECD Name:** ZZK12002A (with an "EDIT" button)
 - ECD Serial:** ZZK12002A
 - ECD Model:** TASER_ECD_X26P
 - ECD Status:** GoodBelow these details are buttons for "PDF REPORT" and "DISCONNECT".
- FIRMWARE:** This section lists the current firmware status for various components:
 - ECD:** FWBundle OK, 03.033, 2012-10-16 16:12:14
 - X26P-HVM:** OK, 00.016, 2011-06-01 10:44:19
 - LDR:** OK, 03.033, 2012-10-16 16:08:04
 - MC:** OK, 03.033, 2012-10-16 16:10:23
 - USB_APP:** OK, 03.033, 2012-10-16 16:09:37
 - USB_LDR:** OK, 03.033, 2012-10-16 16:09:55A note states "This is the latest firmware." and a "CHECK FOR UPDATE" button is provided.
- WARRANTY:** This section indicates "No warranty information is available at this time."
- DEVICE ASSIGNMENT:** This section shows the device is "Assigned to: Michael Dzezinski (2730)". It includes a prompt "To reassign the device, enter the last name of the Officer below:" followed by a text input field labeled "Enter Last Name" and an "ASSIGN" button.

On the right side of the interface, there is an "ACCOUNT" section featuring a user profile picture and the following information:

- Michael Dzezinski**
- Badge: 2730**
- Admin**



TASER
TRAINING ACADEMY

X26P Download


EVIDENCE.COM
Taser Information

Dept. TASER Instructor
Serial ZZX1201MX
Model TASER X26P
Firmware Version Rev. 03.036
Device Name ZZX1201MX
Health Active

Report Generated by

Name Dzezinski, Michael
Badge ID 2730
Local Timezone US Mountain Standard Time (UTC -07:00)
Generated On 17 Dec 2012 12:01:06

Device (X26P)

Seq #	Local Time [dd:mm::yyyy Hr:min:Sec]	Event [Event Type]	Duration [Seconds]	Temp [Degrees Celsius]	Batt Remaining [%]
1	11 Dec 2012 11:09:19	Armed		30	90
2	11 Dec 2012 11:09:21	Trigger	5		90
3	11 Dec 2012 11:09:26	Safe	7	31	89
4	11 Dec 2012 11:09:27	Armed		32	89
5	11 Dec 2012 11:09:28	Trigger	5		89
6	11 Dec 2012 11:09:33	Safe	6	32	89



USB Icons

- When the X26P is connected to the computer via a USB port, the USB icon will show in the display, as well as the serial number of the X26P



TASER
TRAINING ACADEMY